

TILE ROOF-GUTTERS



Step 1 : Roll the 500mm wide mesh across the gutter line. Ensure that you have fastened one end with a clamp or screwed it down to the gutter using a single screw. This is so it temporarily stays in place.



Step 2 : Place mesh over the outer most edge of the gutter (i.e. front lip) and place the trim over the mesh and screw down. Place a screw every 30cms or 12 inches.



Step 3 : Now slit the mesh every second tile. Slit only so far as to the bottom of the base of the second row of tiles. This is done to alleviate the stress from the mesh and allows it to settle properly.



Step 4 : Lift two second row tiles at a time and tuck the mesh under the tiles. Making sure the mesh is well tucked and with no slack.



Step 5 : To avoid damage to pointing or bedding, we stop tucking the mesh about three tiles from the end of the run. The mesh is then cut around the profile of the hip.



Step 6 : Cut under the lip of the second row of tiles



Step 7 : The mesh is then tacked into place with a screw



Step 8 : Then seal with silicone into place. To prevent the mesh from lifting.

WARNING: Ensure that all necessary precautions are taken with regards to safety. UltraGuard accepts no responsibility for personal or other injury as a result of installation. This product may have sharp edges, please handle with care. Information is to be used as a guide only.

