

CORRUGATED ROOF-GUTTERS & VALLEYS

Also use for Trimdeck & Bullnose roofs



Step 1 : Mesh is clamped to beginning edge of gutter.



Step 2 : Trim is fixed to gutter lip



Step 3 : Mesh is then slit every second corrugation. The slit is along each side of the corrugation and should not exceed 20mm.



Step 4 : Saddles are screwed on every second corrugation.



Step 5 : Finish product.



Step 6: With a valley a 250mm or 500mm wide mesh can be used. It is simple rolled out and fastened on every corrugation on either side of the valley with saddles.



Bull Nose Roof Finish



Trim deck Roof Finish

NOTE: For Bull nose & Trimdeck roof follow steps 1-4 of Corrugated roof instructions.

WARNING: Ensure that all necessary precautions are taken with regards to safety. UltraGuard accepts no responsibility for personal or other injury as a result of installation. This product may have sharp edges, please handle with care. Information is to be used as a guide only.

